

Patchcords and pigtails

- Keep connectors clean.
- Put the protective cap back on when not in use.
- The fibre's bend radius must always be greater than 30 mm.
- Do not touch the ferrule prior to installation.
- Make sure each connector is installed properly.

Steps:

1. Wipe around the ferrule twice using lens paper soaked in 99% isopropyl alcohol.
2. Repeat using a wipe intended for delicate tasks.
3. Place a tissue soaked in alcohol on a smooth surface. Keeping the connector perpendicular (at an angle for an APC polish), lightly wipe the surface of the ferrule.
4. Wipe the connector to soak up the excess alcohol. Use a wipe intended for delicate tasks.
5. Hook up the connector or put the cap back on.

Cassettes and motorized cleaners also yield acceptable results.



- ▶ **Before you inspect a connector, always make sure the light source is turned off.**

Questions? | **Contact us at 450 979-2275** | inf@om6.com

Technical features subject to change without notice